


User Manual

Warranty

- **Warranty service is provided for 12 months from the date of purchase.**
- If you have any questions, please feel free to contact us: service@insolife.com
- For more information, please visit: www.insolife.com

1. Packing List




2. Use Guide


A1. How to use



A2. How to switch the High / Low mode



Indicator light




- If no water is detected, the product will automatically shut off after 3 seconds.
- When the product is used upside down, a few drops of water may drip due to water pressure even in the off state, which is a normal phenomenon and will not occur when turned on.

A3. How to replace the showerhead?



- If the showerhead is clogged or the water flow is weak, please clean the filter.

A4. How to use the flip top showerhead?



A5. Which water bottles can the product fit?




Install BottleAdapter
Align the BottleAdapter accessory with the bottom of the product as shown, then rotate clockwise to tighten.

Remove BottleAdapter
Grasp the Bottle Adapter accessory section on the product, then rotate counterclockwise to remove.



- Caution: Before rotating to remove the bottle, grasp the BottleAdapter on the product; otherwise, the BottleAdapter may adhere to the bottle neck.

A6. How to clean the product filter?



3. Technical specifications

- Name: Insolife Bidet 3
- Product diameter: 35 mm
- Product weight: about 80 grams
- Charging time: about 2.5 hours
- Waterproof rating: IPX7
- Bottle capacity: 400mL
- Input voltage / current: 5V $\pm$ 0.5A
- Battery type: Rechargeable polymer lithium battery
- Product height: 97 mm
- Charging port type: USB Type-C
- Bottle material: Polypropylene
- Battery capacity: 350mAh
- Product shell material: ABS

4. Question & Answer

- Q: Can I use an iPhone or Android phone charger to charge?
- A: Yes, as long as it is a Type-C charging cable.
- Q: Can I clean this product by rinsing it with water?
- A: Yes, this product has an IPX7 waterproof rating.
- Q: Why does this product stop running automatically?
- A: 1.The product will automatically stop running 3 seconds after detecting no water.
2.When the battery is low, the indicator light will turn red and the product will stop running, requiring timely charging.
3.The product will stop running automatically when the bottom filter is clogged, please clean the filter promptly.
- Q: How long can this product work continuously?
- A: After fully charged, it can be used continuously for about 40 minutes.
- Q: What should I do if the product malfunctions?
- A: Please contact your local dealer or send an email to service@insolife.com. Please provide us with the purchase channel, order number, and a description of the malfunction, and we will resolve it for you as soon as possible.

5. Warnings

- Please avoid dropping, impacting, or rubbing the product against hard objects.
- Do not use water exceeding 40°C (104°F) to prevent scalding.
- Do not use medicinal solutions or other turbid liquids to avoid damaging the product.
- To avoid the risk of fire and scalding, please do not open, squeeze, heat above 40°C (104°F), or burn the product.
- Please do not place the bottle in water exceeding 40°C (104°F).
- Children should use under adult supervision to ensure their safety.
- This appliance must only be supplied at safety extra low voltage corresponding to the marking on the appliance.
- This product is for external use only. Do not insert it for internal rinsing.